

Design of Parallel and High-Performance Computing

Fall 2013

Lecture: Roofline

Instructor: Torsten Hoefer & Markus Püschel

TA: Timo Schneider



Eidgenössische Technische Hochschule Zürich
Swiss Federal Institute of Technology Zürich

Operational Intensity

- Definition: Given a program P, assume cold (empty) cache

$$\text{Operational intensity: } I(n) = \frac{W(n)}{Q(n)}$$

\leftarrow #flops (input size n)
 \leftarrow #bytes transferred cache \leftrightarrow memory (for input size n)

- Examples: Determine asymptotic bounds on $I(n)$
 - Vector sum: $y = x + y$ $O(1)$
 - Matrix-vector product: $y = Ax$ $O(1)$
 - Fast Fourier transform $O(\log(n))$
 - Matrix-matrix product: $C = AB + C$ $O(n)$

Example MVM: $y = Ax + y$


- Number of flops?
- Number of compulsory misses (cold cache)?
- Upper bound on the operational intensity?

Roofline Measurements

- Tool developed in our group
(G. Ofenbeck, R. Steinmann, V. Caparros-Cabezas, D. Spampinato)
- Example plots follow
- Get bounds on I:
 - daxpy: $y = \alpha x + y$
 - dgemv: $y = Ax + y$
 - dgemm: $C = AB + C$
 - FFT

Roofline Measurements


Core i7 Sandy Bridge, 6 cores
Code: Intel MKL, *sequential*
Cold cache



What happens when we go to parallel code?

Roofline Measurements


Core i7 Sandy Bridge, 6 cores
Code: Intel MKL, *parallel*
Cold cache



What happens when we go to warm cache?

Roofline Measurements

Core i7 Sandy Bridge, 6 cores
Code: Intel MKL, *sequential*
Warm cache



7

Summary

- Roofline plots distinguish between memory and compute bound
- Can be used on paper
- Measurements difficult (performance counters) but doable

8